


RCRA National Conference

January 15-18, 2002

Development of Simple Screening Criteria for the Indoor Air Exposure Pathway


John A. Connor, P.E.
Farrukh Ahmad, Ph.D.
Thomas E. McHugh, Ph.D.
Phillip C. DeBlanc, Ph.D., P.E.
Charles J. Newell, Ph.D., P.E.
Roger J. Pokluda

GROUNDWATER SERVICES, INC.
(713) 522-6300



Screening Criteria for Indoor Air Pathway

- Objectives / Approach
- Site Database: *Evaluation of J-E Model*
- Site Database: *Screening Criteria*
- Recommended Screening Approach



Screening Criteria for Indoor Air Pathway


Project Objectives: *What We Did*

1

Johnson-Ettinger Model:

Evaluate utility as screening-level model.

Rule of Thumb



VS.

2

Empirical Screening Criteria:

Develop simple rules re: absence of indoor vapor exposure risk for fuels and solvents.

Model



GOAL: Using actual site measurements, develop simple screening guidelines for evaluation of indoor air exposure pathway for organic compounds.

Screening Criteria for Indoor Air Pathway

Site Database: *Description*

Sources

- Massachusetts DEP (83 cases) and other published studies (10 cases).

Data Types


- Actual COC conc. measurements in GW (85), soil vapor (8), indoor air (93), and background air.
- Other site info:
Soil type, DTW, foundation type, NAPL

Data Population

- 31 Locations: MA (27), CA (2), NJ (1), Canada (1)
- 93 cases: Individual COC measurements at any site.

KEY POINT:

Database is **NOT** a random sampling. Results biased high as only problem sites were measured and most MA measurements conducted in winter*.



Screening Criteria for Indoor Air Pathway


Johnson-Ettinger Model: *Performance Evaluation*

**Evaluate on
Two Levels**

- **Quantitative Analysis:**
Reliable prediction of indoor vapor concentration?
- **Screening Level Analysis:**
Reliable prediction of indoor vapor RBEL exceedance or non-exceedance?

KEY APPROACH:

Use site-specific inputs for L_s , COC, and C_s to get best indoor vapor estimate, not conservative high estimate.




Screening Criteria for Indoor Air Pathway


J-E Model: Evaluation of Bias C_p vs. C_m

Diffusion-Only Mode: Distribution of C_p/C_m Ratio

All COCs



Fuels



KEY POINT:


Diffusion-only mode shows poor accuracy (10x error 41 % of time for all COCs) but only moderate bias (overpredicts actual concentration 61 % of the time with median C_p/C_m ratio of 2.7 for all COCs, 3 for fuels).

Screening Criteria for Indoor Air Pathway


J-E Model: Evaluation of Bias C_p vs. C_m

Diffusion / Advection Mode: Distribution of C_p/C_m Ratio

All COCs



Fuels



KEY POINT:

Diffusion-Advection mode has poor accuracy (>10 x error 57 % of time) and high bias (overpredicts actual concentration 84 % of time with median C_p/C_m ratio of 12 for all COCs, 20 for fuel COCs).


Screening Criteria for Indoor Air Pathway

J-E Model: Screening-Level Analysis (C_p vs. RBEL)

Performance Criteria for Screening Model

- **Vapor Exposure Level:**
Correctly identifies $C_m < \text{RBEL}$ or $> \text{RBEL}$?
- **False Positive:**
Says $C_m > \text{RBEL}$ or $> \text{Backgrd}$ when not
- **False Negative:**
Says $C_m < \text{RBEL}$ or $< \text{Background}$ when not

GOAL: Useful screening-level model should have no false negative, minimal false positive results re: RBEL exceedance.



Screening Criteria for Indoor Air Pathway









Risk-Based Exposure Limits (RBELs) for Residential Inhalation Exposure

CHEMICALS OF CONCERN		Carcinogenic Inh. RBEL (10^{-6}) (mg/m ³)	Carcinogenic Inh. RBEL (10^{-5}) (mg/m ³)	Noncarcinogenic Inh. RBEL (HQ =1) (mg/m ³)
Solvent COCs	1,1,1-Trichloroethane	N/A	N/A	1.00E+00
	1,1-Dichloroethene	4.90E-05	4.90E-04	N/A
	Tetrachloroethene (PCE)	4.20E-03	4.20E-02	2.80E-01
	Trichloroethene (TCE)	1.40E-03	1.40E-02	N/A
	cis-1,2-Dichloroethene	N/A	N/A	8.30E-01
Fuel COCs	Benzene	3.10E-04	3.10E-03	6.30E-03
	Ethylbenzene	N/A	N/A	1.00E+00
	Toluene	N/A	N/A	4.20E-01
	Xylene, Total	N/A	N/A	4.50E-01
	Metyl tert-Butyl Ether (MTBE)*	5.40E-02	5.40E-01	3.10E+00

- NOTES:**
- 1) * MTBE RBEL at a target risk of 10^{-5} obtained from Texas Risk Reduction Program Tier 1 Tables, 30 TAC 350.
 - 2) Values used in evaluating data are shown in **bold**.
 - 3) RBEL = Risk-Based Exposure Limit.

Screening Criteria for Indoor Air Pathway

J-E Model: Screening-Level Analysis (C_p vs. RBEL)

Performance Criterion	No. Cases	Diffusion Only ($Q_s = 0$) All COCs	No. Cases	Diffusion /Advection ($Q_s > 0$) All COCs
RBEL Exceedance (10^{-6})				
■ False Positive	14	 15 %	27	 29 %
■ False Negative	5	 5 %	2	 2 %
RBEL Exceedance (10^{-5})				
■ False Positive	16	 17 %	30	 32 %
■ False Negative	3	 3 %	1	 1 %

KEY FINDING: Model predictions provide significant false positive results, particularly for diffusion/advection mode.

C_p = Predicted concentration in indoor air; RBEL = Risk-Based Exposure Limit

Screening Criteria for Indoor Air Pathway

J-E Model: Summary Findings

J-E Model

■ ***As Screening Level Tool:***

- 1) **Diffusion-Only Mode:**
Poor accuracy, low-bias model may overpredict or underpredict actual indoor vapor level.
- 2) **Diffusion-Advection Mode:**
Poor accuracy, high-bias model provides high false positive rate on RBEL exceedance.



KEY POINT:

JE model does not provide reliable screening of potential indoor vapor impacts for this database.

Screening Criteria for Indoor Air Pathway

Site Database: *Classification by Vapor Exposure Level*

**Potential
Vapor
Exposure
Level**

< RBEL

C_m

< Greater of Background or RBEL


> RBEL

Greater of Bkgrd or RBEL <

C_m

**APPLICABLE
EXPOSURE
LIMIT:**

**RBEL = Risk-Based Exposure
Limit for residential air inhalation
scenario with HQ = 1,
TR = 10^{-6} or 10^{-5} .**



C_m = Conc. of COC measured in indoor air; HQ = Hazard Quotient; ° RBEL = Risk-Based Exposure Limit; TR = Target Risk

Screening Criteria for Indoor Air Pathway

Vapor Site Database: Classification by Indoor Vapor Level

	TOTAL NO.	MEASURED INDOOR VAPOR LEVEL					
		< RBEL (10^{-6})		> RBEL (10^{-6})		> RBEL (10^{-5})	
		No.	%	No.	%	No.	%
All Cases	93	72	77%	21	23%	13	14%
Fuel COCs	67	59	88%	8	12%	4	6%
■ BTEX	63	56	89%	7	11%	4	6%
■ MTBE	4	3	75%	1	25%	0	0%
Solvent COCs	26	13	50%	13	50%	9	35%

KEY FINDING:

Most fuel sites (88%) are below 10^{-6} RBEL.
Half of solvent sites are above.



BTEX
MTBE
TCE

RBEL = Risk-Based Exposure Limit


Screening Criteria for Indoor Air Pathway

Measured Vapor Levels: *Effect of Soil Type*

SOIL TYPE	TOTAL NO.	MEASURED INDOOR VAPOR LEVEL					
		< RBEL (10^{-6})		> RBEL (10^{-6})		> RBEL (10^{-5})	
		No.	%	No.	%	No.	%
Sand / Gravel	36	27	75%	9	25%	6	17%
Sand	55	43	78%	12	22%	7	13%
Silt / Clay	2	2	100%	0	0%	0	0%

KEY FINDING:

Most sites in database have sand or gravel soils. Silt/clay sites measured show no exposure $> 10^{-6}$ RBEL.



RBEL = Risk-Based Exposure Limit


Screening Criteria for Indoor Air Pathway

Measured Vapor Levels: *Effect of Depth to Source*

Depth to Source Below Foundation	TOTAL NO.	MEASURED INDOOR VAPOR LEVEL					
		< RBEL (10^{-6})		> RBEL (10^{-6})		> RBEL (10^{-5})	
		No.	%	No.	%	No.	%
< 5 ft	13	8	62%	5	38 %	3	23%
5 - 10 ft	60	44	73%	16	27 %	10	17%
> 10 ft	20	20	100%	0	0%	0	0%

KEY FINDING:

For source depths > 10 ft, indoor vapor levels are less than 10^{-6} RBEL for all compounds and all soil types in database.



RBEL = Risk-Based Exposure Limit; Depth to Source = Distance below foundation to affected soil or groundwater source.


Screening Criteria for Indoor Air Pathway

Measured Vapor Levels: Effect of Foundation Type

Foundation Type	TOTAL NO.	MEASURED INDOOR VAPOR LEVEL					
		< RBEL (10^{-6})		> RBEL (10^{-6})		> RBEL (10^{-5})	
		No.	%	No.	%	No.	%
No/Partial Foundation	5	2	40 %	3	60 %	1	20 %
Concrete w/ Basement	48	42	88 %	6	13 %	4	8 %
Concrete, No Basement	30	20	67 %	10	33 %	6	20 %

KEY FINDING:

Higher impacts associated with bare soil, but no additional risk observed with basement.



RBEL = Risk-Based Exposure Limit;


Screening Criteria for Indoor Air Pathway

Measured Vapor Levels: Effect of COC Concentration in GW (C_{gw})

Conc. in GW (C_{gw})	TOTAL NO.	MEASURED INDOOR VAPOR LEVEL			
		< RBEL (10^{-6})		> RBEL (10^{-6})	
		No.	%	No.	%
$C_{gw} \leq 0.5$ mg/L	28	24	86 %	4	14 %
$0.5 < C_{gw} \leq 1$ mg/L	13	9	69 %	4	31 %
$1 < C_{gw} \leq 5$ mg/L	27	21	78 %	6	22 %
$C_{gw} > 5$ mg/L	17	12	71 %	5	29 %

KEY FINDING:

No significant correlation of vapor impact with C_{gw} for either fuels or solvents.



GW = Groundwater; RBEL = Risk-Based Exposure Limit


Screening Criteria for Indoor Air Pathway

Measured Vapor Levels: *Effect of NAPL*

NAPL Condition	MEASURED INDOOR VAPOR LEVEL						
	TOTAL NO.	< RBEL (10 ⁻⁶)		> RBEL (10 ⁻⁶)		> RBEL (10 ⁻⁵)	
		No.	%	No.	%	No.	%
NAPL, Any Depth	10	8	80 %	2	20 %	1	10 %
NAPL, L _s > 10 ft	4	4	100 %	0	0 %	0	0 %
GW Seepage into Basement	3	1	33 %	2	67 %	1	33 %

KEY FINDING:

NAPL not generally indicative of vapor problem and never if depth > 10 ft.
Direct GW seepage = bad news.



RBEL = Risk-Based Exposure Limit; NAPL = Non-aqueous phase liquid

Screening Criteria for Indoor Air Pathway

Measured Vapor Levels: *Key Screening Criteria*

**No Exceedance
of Indoor Air
Risk Limit (10^{-6})**

If:

<i>Empirical Screening Criterion</i>	No. Cases	No. > RBEL (10^{-6})
■ Depth to Source > 10 ft, any COC, any soil, any concentration.	20	0
■ Fuel COC, $L_s > 6$ ft, concentration < 1 mg/L	17	0

KEY FINDING:

For this site database, simple criteria can identify no-risk cases.




Rules of Thumb



L_s = Depth to source below foundation.

Screening Criteria for Indoor Air Pathway

J-E Model vs. Empirical Screening Criteria

		J-E Model: Diffusion-Only Mode	
Site Condition	TOTAL No.	10 ⁻⁶ RBEL	10 ⁻⁵ RBEL
1 <i>L_s > 10 ft, All COCs</i>	20	FP:  2 %	FP:  15%
		FN: 0 %	FN:  5%
2 <i>Fuels, L_s > 6 ft, COC < 1 mg/L in GW</i>	18	FP: 0 %	FP: 0 %
		FN: 0 %	FN: 0 %





KEY FINDING:

Diffusion-only model overpredicts vapor impacts from deep sources (> 10 ft) but OK with "fuel rule."

COCs = Constituents of Concern; FP = False Positive; FN = False Negative; RBEL = Risk-Based Exposure Limit

Screening Criteria for Indoor Air Pathway

J-E Model vs. Empirical Screening Criteria

		J-E Model: Diffusion / Advection Mode	
Site Condition	TOTAL No.	10^{-6} RBEL	10^{-5} RBEL
1 $L_s > 10$ ft	20	FP:  50 % FN: 0 %	 45 % FN: 0 %
2 Fuels, $L_s > 6$ ft, COC < 1 mg/L in GW	18	FP:  11 % FN: 0 %	FP:  11 % FN: 0 %

KEY FINDING:

Advection-mode model more significantly overpredicts vapor impacts from deep sources (> 10 ft), moderately overpredicts for "fuel rule."

FP = False Positive; FN = False Negative; RBEL = Risk-Based Exposure Limit

Screening Criteria for Indoor Air Pathway

Recommended Approach

Empirical Screening Criteria

- **Soil Type, Depth, Etc.:** Always use as first step in pathway screening process.




Screening Model (Optional)

- **JE, Others:** Use improved model as optional screening tool to eliminate sites from further evaluation.



Site Measurements

- **Indoor Air or Soil Vapors:**
When appropriate, conduct soil vapor or direct indoor air sampling but must correct for other sources, background levels, etc.



Screening Criteria for Indoor Air Pathway

Further Work Needed

- ***Additional Site Data:***
Compile more data, for all soil types, to confirm / refine screening criteria.
- ***Sampling Guidelines:***
Identify reliable methods for measurement and interpretation of vapor levels in subsurface and indoors.
- ***Transient Effects and Biodegradation:***
Characterize effect of soil type & other site-specific factors on vapor transport times & biodegradation rates.

